ASSEMBLY INSTRUCTION FOR ACME FURNITURE MODEL #BD00954

Thank you for purchasing the quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, Identify and count all parts and metal hardware. Compare with all parts list to be sure all parts are present. If any part(s) are missing or damaged, please contact your local furniture dealer. For efficient and speedy service, please indicate the model number and code letter of part(s) needed.


**Do not fully tighten screws until fully assembled*

| | COMPONENT PARTS | | | | | |
|-------------|--------------------------------------|-----------|----|--|--|--|
| DESCRIPTION | PART NA | Q'TY(PCS) | | | | |
| 1 | ARM (L&R) | | 2 | | | |
| 2 | TOP BACK PANEL | | 1 | | | |
| 3 | TOP SIDE RAILS | | 2 | | | |
| 4 | BOTTOM FRONT PANEL | | 1 | | | |
| 5 | BOTTOM BACK PANEL | | 1 | | | |
| 6 | BOTTOM SIDE PANELS | | 2 | | | |
| 7 | SLATS (TOP) | | 13 | | | |
| 8 | SLATS (BOTTOM) | | 12 | | | |
| 9 | TOP CENTRE WOOD SUPPORTOR (LONG) | | 1 | | | |
| (10) | BOTTOM CENTRE WOOD SUPPORTOR (SHORT) | | 1 | | | |
| 11) | FOOT | | 4 | | | |

Page 1/7

HARDWARE REQUIRED

| A | | BOLT | 5/16 x1-1/2" | 8 | PCS |
|---|--------------------|-------------------|---------------|----|-----|
| В | | BOLT | 5/16 x 2-1/2" | 4 | PCS |
| С | | BOLT | 5/16 x 3/4" | 8 | PCS |
| D | | SPRING WASHER | 5/16" | 20 | PCS |
| E | | FLAT WASHER 5/16" | 19mm | 16 | PCS |
| F | | FLAT WASHER 5/16" | 22mm | 4 | PCS |
| G | [] mmm> | SCREW #8 | 1-1/4" | 75 | PCS |
| Н | | SCREW #8 | 2-1/4" | 16 | PCS |
| | | ALLEN KEY | 5mm | 1 | PC |



Attention:

***Some number parts listed on the instruction sheet may not be in parts bag as they may already be assembled. Carefully check parts and parking materials prior to ordering replacements.

